

Product Assembly Instructions

Item#: SANTORINI BARSTOOL

Helpers needed to assemble: 2

Estimated time frame to assemble: 10 minutes

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may come loose inside the carton during shipment. Please identify and count all parts and compare with the **HARDWARE LIST** below.

Caution: Please read instructions carefully before unpacking assembly parts. Sharp, exposed staples can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

*** Retain the Allen key for regular maintenance. We recommend tightening all screws every three months to ensure continued stability and performance. ***

Step 1:







Before beginning assembly, place all parts on a smooth, flat surface.

Place the Seat Frame (B) upside down on a soft surface. Align the Frame Legs (A) with the pre-drilled holes on the swivel plate of the Seat Frame (B).

Insert 4pcs Bolts $\text{\O}1/4'' \times 1''$ (1) with Flat Washers (2) and Spring Washers (3) as shown, and tighten using the Allen Key (4).

Ensure the holes on the swivel plate are properly aligned with the holes on the Frame Legs (A) before fully tightening.

Your assembly is complete — enjoy your new barstool!

#	Picture	Description	Q'TY.
A		Frame leg	1
B		Seat frame	1
1		$\text{\O}1/4'' \times 1''$ Bolts	4
2		$\text{\O}1/4'' \times \text{\O}16$ Flat washer	4
3		$\text{\O}1/4'' \times \text{\O}10$ Spring washer	4
4		Allen key	1

STEP 1

