

Product Assembly Instructions

Item# : LCAISISAWA, LCAISICHTWA, LCAISILWA & LCAISIPPWA - AMARIS DINING CHAIR

Helpers needed to assemble: 2








Estimate time frame to assemble: 10 minutes








Thank you for purchasing this quantity product. Be sure to check all packing material carefully for small parts, which may come loose inside the carton during shipment. Please identify and count all parts and compare with the HARDWARE LIST below.

Caution: Please read instructions carefully before unpacking assembly parts. Sharp, exposed staples can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


*Keep the Allen Key and Tighten all screws each 3 months for safety concern!

1. We recommend to assemble this product with the assistance of another person. This will provide a smooth assembly process, and can help eliminate self injuries or damage to the product during assembly.
2. Please do not over tighten screws or bolts until the assembly is completed.
3. Please put all parts on a smooth, flat surface before assembly, and carefully follow the assembly steps to assemble your newly purchased product correctly and efficiently.


#	Part List	QTY
A	Left Chair Side Legs 	4
B	Right Chair Side Legs 	4
C	Long Stretcher 	4
D	Centre Stretcher 	4
E	Short Stretcher 	4
F	Seat Cushion 	4
G	Backrest Cushion 	4

#	Hardware List	QTY
1	Jcbc Bolt M6 X 30mm 	16
2	Jcbc Bolt M6 X 40mm 	16
3	Spring Washer M6 	16
4	M8 X 30mm Wood Dowel 	16
5	CSK Screw M4 X 32mm 	16
6	Allen Key 	1
7	Wood Button 	16


Step 1:



Step 2:



Step 3:



Step 4:

