



Product Assembly Instructions

Item#:EMBER OD COFFEE TABLE


SKU: LCEBCONAT



Thank you for purchasing this quality product.

- Be sure to check all packing material carefully for small parts, which may come loose inside the carton during shipment.
- Please identify and count all parts and compare them with the HARDWARE LIST below.
- Caution: Please read instructions carefully before unpacking assembly parts. Sharp, exposed staples can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


* Keep the Allen Key and Tighten all screws each 3 months for safety concern!



1. We recommend assembling this product with the assistance of another person. This will provide a smooth assembly process and can help eliminate self-injuries or damage to the product during assembly.
2. Please do not overtighten screws or bolts until the assembly is completed.
3. Please put all parts on a smooth, flat surface before assembly, and carefully follow the assembly steps to assemble your newly purchased product correctly and efficiently.



#	Image	Description	Quantity
1		Tabletop	1
2		Table leg	2
3		JCBC M6 x 50mm bolt	8
4		Spring washer	8
5		Flat washer	8
6		Allen wrench	1

- **Step 1:** Place the tabletop (1) upside down on a clean, smooth surface to prevent scratches. Attach the two table legs (2) to the tabletop using 8 pcs JCBC M6 x 50 mm bolts (3), 8 pcs spring washers (4), and 8 pcs flat washers (5). Use the Allen wrench (6) provided and tighten all bolts securely.





Adjustable leveler

Assembly is complete