


Item # : LCLNBADCAG26 / LCLNBATTWH26 Lenon 26" Backless Barstool LCLNBADCAG30 / LCLNBATTWH30 Lenon 30" Backless Barstool

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may come loose inside the carton during shipment . Please identify and count all parts and compare with the HARDWARE LIST below.


Caution : Please read instructions carefully before unpacking assembly parts. Sharp , exposed staples can cause injury , therefore , for your protection , please remove any exposed staples used in packing.

*** Retain the Allen key for regular maintenance. We recommend tightening all screws every three months to ensure continued stability and performance. ***

1. We recommend to assemble this product with the assistance of another person. This will provide a smooth assembly process , and can help eliminate self injuries or damage to the product during assembly.
2. Please do not over tighten screws or bolt until the assembly is completed.
3. Please put all parts on a smooth , flat surface before assembly , and carefully follow the assembly steps to assemble your newly purchased correctly and efficiently.




PARTS LIST		
NO.	COMPONENT	QTY.
A	Seat 	1 pc
B	Side Leg 	2 pcs
C	Long Stretcher 	2 pcs
D	Short Stretcher 	2 pcs

HARDWARE LIST		
NO.	COMPONENT	QTY.
1	JCBC Bolt M6 x 50mm 	4 pcs
2	Spring Washer 	4 pcs
3	CB Screw M4 x 38mm 	8 pcs
4	Allen Wrench 	1 pc


* Phillips screwdriver not included *

Step 1



Attach Long Stretcher (C) and Short Stretcher (D) to Side Leg (B) using 8pcs CB Screw (3) and tighten them securely with Phillips screwdriver .
(not provided).

Step 2



Attach the leg base to the Seat (A) using 4pcs JCBC bolts (1) and 4pcs Spring Washers (2). Tighten all bolts securely with Allen Wrench (4).

